

Guide Specification

Issued: June 1997
Revised: September 2007
Replaces: April 2001

Cem-Kote Flex CR - Concrete Tank Restoration, Waterproofing & Protection**PART I: GENERAL****1.1 Description**

- A. This specification is for installation of Cem-Kote Flex CR, flexible cementitious waterproofing coating manufactured by **Gemite Products Inc.** The material is suitable for concrete waterproofing, finishing and protection. Cem-Kote Flex CR provides an excellent protection of concrete against acidic attack of H₂SO₄, formed by bacteriological conversion of H₂S in sewers, waste water treatment facilities, lift stations, "wet wells" and oxidation tanks. This specification should be read in conjunction with Cem-Kote Flex CR Product Data Sheets and Cem-Kote Flex CR Installation Instructions. **Gemite Products Inc.** offers comprehensive technical assistance to consultants when specifying the products and systems.
- B. The general conditions, supplementary conditions and general requirements of this document apply to General Contractors, Sub-Contractors, Material Suppliers and all other persons furnishing labor and materials under this section.
- C. This specification combines Metric measurements and US. Brackets () indicate choice, alternative, data required or need for the specifier to make a decision.

1.2 Work Included

Provide all labor, material and equipment necessary to apply Cem-Kote Flex CR in application over concrete surfaces as shown on the contract drawings and specified herein.

1.3 Related Work

Insert list of divisions and sections where related or allied work is specified, such as concrete slab, wall, tank balconies and other types of concrete waterproofing, finishing and protection. See Cem-Kote Flex CR Product Data Sheets.

1.4 Quality Assurance

- A. The contractor will provide the proper equipment, manpower and supervision at the job site to install Cem-Kote Flex CR in compliance with the project plans and specifications.
- B. Prepare a site sample approximately 1200mm x 1200mm (4' x 4'). This sample will be regarded as the minimum standard of workmanship acceptable for this project.
- C. The applicator must be an approved applicator by Gemite Products Inc. Key tradesmen on the site must be factory trained in the product mixing and application procedures prior to commencing work.
- D. Maintain a record of the batch numbers of all materials supplied for this project.

1.5 Submittals

- A. Provide owner with manufacturer's literature, including Specification Guides, Product Data Sheets and installation instructions, for all products used to complete project
- B. Submit documentation that Quality Assurance criteria have been met

1.6 Product Delivery, Storage and Handling

- A. Deliver materials to the site in original, unopened and undamaged packaging with manufacturer's identification and labels intact.

- B. Store Cem-Kote Flex CR in a clean, dry area protected from direct sunlight, weather and other damage. Store all wet materials at a temperature of not less than 5°C (44°F) at all times.
- C. Material Safety Data Sheets (MSDS) will be available at the job site.

1.7 Alternates

Obtain written permission from the owner's representative at least ten days prior to close of tender. The alternate material must have been in use for a minimum of eight years.

1.8 Standards

All reference standards will be the most current version of these specifications:

- a. Rubber Properties in Tension (ASTM D 412 – modified)
- b. Water Vapor Transmission (ASTM E 96 “Wet Cup” procedure)
- c. Salt Scaling Resistance (ASTM C 672)
- d. Hydraulic Impermeability (TT-P-1411)
- e. Tensile Properties of Thin Cement Composites (Gemite ISO TP (Test Procedure) 005-97)

1.9 Job Site Conditions

- A. Cem-Kote Flex CR materials must never be applied if ambient temperatures cannot be kept above 4°C (40°F) during application and for 48 hours thereafter. Avoid applications at temperatures above 28°C (82°F)
- B. Protect surrounding surfaces from damage due to work of this trade.

1.10 Co-ordination/Scheduling

The work in this section requires close co-ordination with related sections and trades.

2 PART II PRODUCTS

2.1 Manufacturers

- A. Manufacturer's materials are specified by brand name to establish a standard quality, by general description of product and by performance requirements. The Engineer will consider substitutions for brand name products specified, if the procedures set out for substitutions are followed. The Engineer reserves the right to reject any material, which, in his opinion, will not produce the quality of work, specified herein.
- B. The following are acceptable manufacturers: **Gemite Products Inc.** or approved equal.

2.2 Materials - General

- A. Cem-Kote Flex CR - supplied as a Kit comprising of dry Component A + Liquid Component B, as manufactured by Gemite Products Inc.
- B. Reinforcing Fabric HD - supplied in rolls 48" (122 cm) wide and 45.7 m (150') long, for application on the entire surface when required, supplied by Gemite Products Inc.
- C. Reinforcing Fabric NW – supplied in rolls 10 cm (4 in) wide as 50 m (164 ft) long for crack treatment.
- D. Cem-Kote Flex PLUS - supplied as a Kit comprising of dry Component A + Liquid Component B, as manufactured by Gemite Products Inc.
- E. Gem-Plast TC - thin set concrete restoration mortar, manufactured by Gemite Products Inc.
- F. Fibre-Patch OV - restoration mortar for coving of corners, “thin to thick” repairs, OV (overhead, vertical, horizontal), manufactured by Gemite Products Inc.

3 PART III: EXECUTION

3.1 Inspection

- A. Inspect surfaces to which Cem-Kote Flex CR will be applied.
- B. Report to owner's representative, in writing, any defects in previously prepared work, or unsatisfactory

site conditions. Proceed with work under this section only when such defects have been entirely corrected.

- C. Starting work under this section means acceptance of the surface and previously prepared work.

3.2 Surface Preparation

- A. Surface Preparation: High-pressure wash, 4-6,000 psi (42 MPa), or wet or dry sandblast to thoroughly clean the surface and remove soft concrete surface and any bond inhibiting material, such as form oil. Wash the surface thoroughly with water prior to the application and allow to dry off to achieve a SSD (Saturated Surface Dry) condition. When in doubt do a bond test to assure proper surface preparation is being done, or if any additional cleaning is required.
- B. Surface Repair: Use Gem-Plast TC Premix to patch the "honeycombing" and air pockets. Use Fibre-Patch Premix, OV (overhead & vertical, horizontal) for deeper patching. Uneven concrete due to concrete form misplacement must be chipped away and surface patched smooth. Uneven concrete due to form misplacement must be chipped away and surface patched smooth. Build corner coves, 2" x 2" (5 x 5 cm) minimum, using Fibre-Patch OV.
- C. Treatment of Existing Cracks & All Non-Structural Joints: Identify all the existing cracks and joints and apply a layer of Cem-Kote Flex PLUS, approximately 12 cm (5 in) wide and 1-1.5 mm (3/64"-1/16") thick, by trowel or squeegee. Embed the Reinforcing Fabric NW over the entire area of Cem-Kote Flex PLUS and work into the Cem-Kote FLEX PLUS, using trowel. Cem-Kote FLEX PLUS must totally cover the Reinforcing Fabric NW.

Note: In some cases, in new construction, the Reinforcing Fabric HD may be used throughout, since it is unknown where the crack will be formed. The fabric is there to allow the maximum crack spanning during the formation of a crack after installation of the membrane.

In existing facilities the Reinforcing Fabric NW is used over the existing (non-structural) cracks and joints and HD Fabric over any "coved" joints. Contact Gemite Technical Service for assistance.

3.3 Mixing

- A. Mix the content of the bag, Component A with the liquid component B. Use a heavy-duty drill (400-600 RPM) with a helix screw, or paddle mixer to achieve a thorough mixing.
- B. Pour approximately 80% of the liquid component B into the mixing container (mixer) and **gradually add the dry Component A into the liquid** and mix until a smooth and lump free mix is obtained. Lumps will form if the dry material is added suddenly into the liquid. Depending on application, add the remaining liquid as required for a given application consistency. A small amount (1/2 coffee cup) of water can be added, if required, at high ambient temperatures.

3.4 Application

- A. Application. Brush, or spray apply the first coat of Cem-Kote Flex CR. When using spraying, it is necessary to brush the first coat to eliminate the "pin holes". As soon as the first layer allows the next application, apply the second coat. This can take 15 to 30 minutes depending on the environmental conditions such as temperature, relative humidity, sun, wind, etc. The thickness of the first coat should be approximately 1/32 in (0.8 mm). The second coat is applied at the same thickness as the first coat to a total thickness of approximately 1.6 mm. Cem-Kote Flex CR, if necessary, can be applied at the total maximum thickness of 6 mm. Protect against surface water evaporation. Under hot, sunny and windy conditions, extreme care must be given to protect the surface against rapid evaporation of water. The second coat is applied into the "wet – green" first coat. In case the first coat is let to dry by accident, e.g. breakage of equipment, rain, etc. resulting in several hours or till the next day drying, wash the surface thoroughly with 24 MPa, (3,500 psi) water minimum, to clean the surface of the laitance. This procedure should be used only as an emergency procedure in cases described above.

For spraying use peristaltic, moyno or diaphragm pumps. Cem-Kote Flex CR contains fine silica sand and requires plastering nozzles. Please contact Gemite Technical Service for names of the manufacturers of suitable equipments. When spraying, each layer needs to be brushed or trowel finished to eliminate pin-holes and achieve uniform thickness. When a smooth surface is required, the second layer is finished either with a fine brush or trowel. Supply a sample for the engineer or client for approval.

- B. When applying the Reinforcing Fabric NW over the cracks only, embed the fabric into the first, brushed coat, and apply the second coat in sufficient quantity to "cover" the Reinforcing Fabric NW.

- C. When applying the Reinforcing Fabric HD over the entire surface, use the same procedure as described in "B". Overlap the fabric by a minimum of 1 in (2.54 cm). Avoid "sharp" corners. Apply Fibre-Patch material into the corner to form a cove and a gradual transfer from one side to the other side of the corner.
- D. Finishing. Cem-Kote Flex CR can be left with "brushed" surface. In application where a smooth surface is required, e.g. waste water treatment facilities, swimming pools the surface must be "closed" using a steel trowel.
- E. Curing. Air-dry cure Cem-Kote Flex CR for 48 hours.
- F. Hot Weather Application: Protect the surface against rapid evaporation of water between the finishing and the final set time. Use water misting or apply a surface evaporation retarder.
- G. Cold Weather Application: Apply in temperatures above the freezing point and protect the material against freezing for a minimum of 48 hours. Use electrical, (**NOT propane**) heaters to avoid carbonation and carbonation cracking.

3.5 Site Cleanup

All excess and waste materials are to be removed from the job site by the contractor in accordance with contract provisions. Surrounding areas where the material has been applied will be left free of debris.